

OPERATING MANUAL

TCAT-2AC CONTROLLER

CONTENTS

SECTION		PAGE
1.0	GENERAL DESCRIPTION	2
2.0	UNPACKING AND CHECKING CONTENTS	2
3.0	SETTING UP THE TCAT-2AC	3
4.0	OPERATING INSTRUCTIONS	4
5.0	SPECIFICATIONS	5
6.0	MAINTENANCE, WARRANTY AND SERVICE	6