

OPERATING MANUAL

**BFS-MP FREEZING STAGES
FOR MICROTOMES**

BFS-3MP, BFS-5MP, BFS-40MP

CONTENTS

SECTION		PAGE
1.0	GENERAL DESCRIPTION	2
2.0	UNPACKING AND CHECKING CONTENTS	2
3.0	SETTING UP THE SYSTEM	3
4.0	OPERATING INSTRUCTIONS	4
	4.6 Setting Stage Temperature	
	4.7 Removing Specimen from Stage	
	4.8 Typical Stage Performance	
5.0	TROUBLE SHOOTING	5
6.0	SPECIFICATIONS	7
7.0	MAINTENANCE, WARRANTY AND SERVICE	8
	Appendix 1: Operating Instructions for Physitemp Pump and Tank Units	9
	Appendix 2: Operating Instructions for ECV-1 Electrically Controlled Solenoid Valve	10